



TECHNICAL MANUAL

**Operating and Maintenance
Instructions for**

V94 BULK TAPE DEGAUSSER

TECHNICAL MANUAL

Document No. M000208

Production Standard

ZZ 009 415

WARNING To help minimise the possibility of electrical shock hazards under no circumstances should any panels be removed

CAUTION It is recommended that magnetic storage media is kept at least two metres from the degausser

Copyright

This document is the property of Verity Systems Limited and it may not be reproduced, copied or exhibited to a third party without the written permission of Verity Systems.

VERITY SYSTEMS LIMITED

Verity House
2 Eastern Road
Aldershot
Hampshire GU12 4TD
UK

Tel: +44 (0) 1252 317000
Fax: +44 (0) 1252 316555
E-Mail: uksales@veritysystems.com
Web Page: www.veritysystems.com

VERITY SYSTEMS INC.

6236A Main Street
El Dorado
California
CA 95623
USA

Tel: 530 626 9363
Freephone: 1-800 642 5151
Fax: 530 626 9395
E-mail: ussales@veritysystems.com

CONTENTS

SECTION		PAGE
	List of Contents (this page)	3
1	Specification	4
2	Introduction	5
3	Installation	6
4	Operation	7
5	Indicators/Features	8
6	Maintenance/Service	9
7	Basic Fault Finding	10/11
8	Parts List	12

CIRCUIT DIAGRAM

Tables

1	Basic Fault Finding Table
2	Current Monitor Test Points

V94 SPECIFICATION

Depth of Erasure	-75dB on 850 Oersted tape
Media Capacity	Reels - 1/4", 1/2", 1" maximum diameter 15" Cassettes - most oxide cassettes including VHS, Betacam, Umatic, DC600, DC2000, 3480, S-VHS. Floppy Disks - all formats
Power Requirements (factory set)	
Line voltage	220/240v
Line frequency	50Hz
Current (typical)	2.5A
Protection	
Fuse	5A
Antisurge	
Erase time (Double pass)	10 seconds
Run time	10 minutes typical
Duty cycle	30 % to 50% depending on ambient air temperature
Mounting	Free standing table top
Overall Dimensions	Depth 14.3 inches (363mm) Width 13.9 inches (353mm) Height 4.9 inches (124mm)
Weight	approximately 10.5Kg

2 INTRODUCTION TO THE V94 DEGAUSSER

A magnetic recording process is almost always preceded by an erasing process, either by bulk degaussing or by magnetic head erasure. Erasure is a fundamental step in achieving high quality recordings.

Bulk erasure is the preferred method due to the considerable reduction in time involved plus the otherwise use of expensive record/reproduce/erase equipment.

The V94 bulk degausser functions like a large electro magnet, its erasing field originating as leakage flux from a large gap in the field structure, the V94 structure is basically a U section. The field intensity decreases rapidly as the distance from the degausser surface increases. For example at a distance of approximately 2.75 inches from the degausser's surface a field strength of only 30 oersteds exists. Furthermore, the erasing field present at the front edge nearest the operator is also very low. It is therefore recommended that care should be taken to ensure the entire width of tape to be erased is exposed to the effective field.

3. INSTALLATION

3.1 Unpacking

Unpack the degausser carefully, and inspect it for signs of physical damage. If damage is apparent, a claim should be filed with the courier.

3.2 Power Requirements

Check the power supply requirements on the label attached to the back of the equipment with the available supply. The unit is supplied with a flying 3 wire cable which, when plugged into a properly wired receptacle, earths the unit. It is essential that a proper earth connection is made to assure safe operation.

Caution:

A good electrical ground must be connected to the degausser. The unit must be connected to the correct power supply. Failure to do so may result in permanent damage.

Connections

Wire Colour	50Hz unit
Brown	Live
Blue	Neutral
Yellow/Green	Earth

4 OPERATION

WARNING

**STRONG MAGNETIC FIELDS ARE GENERATED.
REMOVE WATCHES BEFORE USE**

**OPERATING PERIODS IN EXCESS OF SPECIFIED
DURATION WILL RESULT IN EXTERIOR SURFACES
BECOMING VERY HOT.**

The V94 degausser has been designed for simplicity of operation in that it consists basically of a flat bed over which the magnetic media is passed or rotated. Control is via a single on/off switch and indicator.

4.1 Media should be erased as follows:

VHS Cassettes:

1. Switch bulk eraser unit ON.
2. Bring cassette slowly to the right hand side of the bulk eraser surface.
3. Using the guide bar, slide the cassette across the eraser surface in a continuous movement taking approximately 4/5 seconds, removing the cassette from the left hand side.
4. Turn cassette through 90 degrees and repeat steps 2 and 3.
5. Turn cassette over and repeat steps 2, 3 and 4.
6. If no further cassettes are to be erased, switch bulk eraser OFF to conserve power and reduce the risk of accidental erasure.

5 INDICATORS/FEATURES

5.1 Indicator

The erase indicator is provided to give an indication of degausser coil energisation. Certain circumstances can arise when, although the unit is switched on, the degauss coils may not be energised.

5.2 Cooling

Forced air cooling of the degaussing coil is provided to maximise the run time. The fan operation is thermostatically controlled.

5.3 Overheat Protection

The high energy field developed by the V94 necessitates the generation of a considerable amount of heat.

The degausser coil is monitored for excessively high temperatures and should this condition occur its operation will be inhibited until the coil has cooled sufficiently.

5.4 Protection

The unit is protected by a 5 Amp fuse of the slow blow or antisurge type.

6 MAINTENANCE/SERVICING

The unit is basically maintenance free but periodic checks should be made to ensure the good condition of the power cable and correct operation of the cooling fan.

Note

To reduce the risk of shock hazard disconnect the degausser from the mains voltage supply before carrying out any maintenance or servicing.

6.1 Fuse replacement

To replace the fuse, rotate the cap in an anticlockwise direction and remove the cap complete with the fuse. Renew the fuse and replace the cap and tighten in a clockwise direction.

6.2 Internal Components

Most of the internal components are replaceable, ie the tuning capacitor and the thermal switch mounted on the degausser coil.

To access the components inside the degausser the laminate cover must be removed. This entails breaking the adhesive seal using a sharp blade.

6.3.1 Thermal Switch Replacement

Care must be exercised when replacing switches on the degausser coil. The switches are fitted with an epoxy resin and it is recommended that the new switch be fitted in a new position on the coil and the old switch be left in place. The wire connections are of the 'push on' spade type and are easily transferred to the new switch. A high temperature epoxy resin part no. EA 200 001 should be used to secure the new switch.

6.3.2 Tuning Capacitor

The capacitor is secured by a simple screw clip and connections are made via push on spade connectors, allowing easy replacement in the event of failure.

6.3.3 Cover replacement

The formica cover should be cleaned of old adhesive before refitting, using the sealant part no. EA 100 007.

7 BASIC FAULT FINDING Table 1

Note

The table assists fault finding down to component levels.

Function	Symptoms	Possible Fault	Location
Fails to degauss media	Fuse F1 repeatedly blown	Incorrect supply voltage/frequency	User source
		Faulty switch corner	Front left hand
		Faulty degauss coil L1 and/or tuning side capacitor C1	Inside centre and left hand
Power lamp	Fails to illuminate	Loss of mains supply F1 fuse blown Faulty switch	User source Rear panel Front panel
		Unit overheated Faulty temperature sensor. side Faulty lamp.	Secured to coil L1 front left hand

CURRENT MONITOR TESTS

The following table contains typical current values to be measured at specific points in the equipment.

The values given are in amperes and may differ slightly from those actually measured due to component tolerance plus effects due to operating temperature.

**Current monitor Test Points
(refer to circuit diagram)**

Model Voltage/Frequency	TEST POINT	
	1	2
220/240v 50Hz	2.5A	5.8A

V94 BULK TAPE DEGAUSSER**8 PARTS LIST (220/240v 50Hz)**

Designation	Part no.	Quantity	Description
	CA 100 005	1	Cable gland 16mm
F1	FF 100 001	1	Fuse 5A
F1	FF 200 006	1	Fuse holder
	FM 100 037	1	Ventilation grill 80mm
F1	FM 100 013	1	Fan 80mm
	HS 100 101	4	Feet
IND1	OI 100 005	1	Indicator
C1	CC 100 093	1	Capacitor 41uf
	MP 002 141	1	Coil Stack Assembly
	MP 001 588	1	Capacitor Clip
SW1	SW 100 014	1	Switch, red
SW2	SW 100 060	2	Thermal Switch 90deg
SW3	SW 100 062	1	Thermal Switch 50deg
	XX 002 503	1	Top Cover
	XX 001 142	1	Guide bar

Manufacturer:

VERITY SYSTEMS LIMITED

Verity House, 2 Eastern Road
Aldershot, Hants, GU12 4TD, UK
Tel: +44 1252 317000
Fax: +44 1252 316555
E-mail: uksales@veritysystems.com

VERITY SYSTEMS INC

6236-A Main Street
El Dorado, CA 95623, U.S.A.
Tel: 530 626 9363
Fax: 530 626 9395
Email: ussales@veritysystems.co

Web Site: <http://www.veritysystems.com>